


Theatre to Control Room Intercom System - Pulse

Ring Communications (UK) Ltd Newmarket Business Centre 341 Exning Road Newmarket, Suffolk, CB8 0AT Tel: +44(0) 1638 660 629 E-Mail sales@ringuk.com Web: www.ringuk.co.uk



Installation

Desk/wall station should be mounted with easy access to controls. System Control Box can be mounted in the ceiling, but may require random access. Cable between Desk/wall Station and the System Control Box is CAT5 cable. Cable for microphone should be microphone cable, 2 core plus Screen. The speaker requires 2 core speaker cable.

Recommendations

Microphone must be fitted where it can pickup speech and not equipment noise. Loudspeaker and Microphone must be spaced so that there is no Feedback, More than one metre apart.

Operation

To communicate with the staff on the theatre press the "Call" key , this will open the communication system in Listen only mode , then press and hold the "PTT" key to talk to the theatre, let go to return to listen mode

Staff in the theatre cannot hear operator without the "PTT" key being pressed When Pressing the "PTT" key the relay will cut music from Avid if fitted.

Close System

To cancel all communications (Switch OFF) press key "Close".